




387502002.




387050002.
387050021.




387503002.




381901002.



389050002.
389050021.



389001002.
389001021.



389001002
389001021



- ES** Utilizar trapo humedo.
- EN** Use damp rag.
- FR** Utiliser un chiffon humide.
- NL** Gebruik een vochtige doek.

- PT** Utilizar um pano húmido.
- IT** Utilizzare una stoffa umida .
- DE** Nicht für die Spülmaschine geeignet.



- ES** No utilizar lavavajillas.
- EN** Do not use dishwasher.
- FR** Ne pas utiliser de lave-vasselle.
- NL** Niet in de vaatwasmachine plaatsen.

- PT** Não utilizar detergentes.
- IT** Non utilizzare lavastoviglie.
- DE** Nicht für die Spülmaschine geeignet.



- ES** No utilizar productos de limpieza que contengan ácidos, vinagre o que sean abrasivos.
- EN** Do not use any cleaning agents containing acid or scouring agents.
- FR** Ne pas utiliser des produits d'entretien qui contiennent des acides, du vinaigre ou qui soient abrasifs.
- PT** Não utilizar produtos de limpeza que contenham ácidos, vinagre ou que sejam abrasivos .
- IT** Non utilizzare prodotti di pulizia con degli acidi, aceto o degli abrasivi.
- DE** Es dürfen keine scharfen Reinigungsmittel die Säuren oder Essig enthalten, sowie sandhaltigen Scheuermittel.
- NL** Geen producten gebruiken die zuren of azijn bevatten of die schurend zijn.